

1 Gebruik van de jacuzzi door de huurders.


- ✓ De huurders gebruiken de jacuzzi **ALLEEN in de GEBRUIKERS "WELCOM" mode !!**
- ✓ De jacuzzi staat **bij GEEN GEBRUIK ALTIJD in CONFIG "- - - -" mode**


1.1 **VOOR** gebruik jacuzzi

Ga je de jacuzzi gebruiken, dan zet je eerst de jacuzzi in de **GEBRUIKERS "WELCOM" mode !!**

- Hiermee zal de klok en de automatische configuratie voor dagelijks verwarmen en filteren ongewijzigd blijven. Als de huurder de jacuzzi gebruikt in de **CONFIG "- - - -" mode**, bestaat de kans dat je de configuratie per ongeluk wijzigt.
- Gebruik de jacuzzi en de knopjes **als huurder NOOIT in de CONFIG mode "- - - -"**.

Zet de jacuzzi bij gebruik **ALS EERSTE in de GEBRUIKERS mode:**

1. Ontgrendel de jacuzzi door op de knop "UNLOCK"  te drukken.
2. Check in welke mode de jacuzzi staat.
 - I. Gebruikers mode >> op het scherm zie je dan: "WELCOM"
 - II. CONFIG mode >> op het scherm zie je dan: " - - - -"


3. Met de rode knop "UIT"  kan je de jacuzzi van **STATUS IN MODE** switchen. Zet de jacuzzi in de GEBRUIKERS mode >> Op het scherm verschijnt dan: "WELCOM"

1.2 **NA** gebruik jacuzzi

Ga je de jacuzzi uit en de jacuzzi afsluiten. Zorg dan dat je de jacuzzi **ALTIJD terug zet in de CONFIG "- - - -" mode.**

- Hiermee zorg je dat het dagelijks automatisch verwarmings- en filter proces zijn werk kan doen, zodat je de volgende dag ook weer een verwarmde en schone jacuzzi hebt.
- Laat de jacuzzi na afloop als huurder **NOOIT** staan in de **GEBRUIKERS mode "WELCOM"**.

Zet de jacuzzi **NA gebruik TERUG in de CONFIG mode:**

1. Ontgrendel de jacuzzi door op de knop "UNLOCK"  te drukken.
2. Check in welke mode de jacuzzi staat.
3. Met de rode knop "UIT"  kan je de jacuzzi van **STATUS IN MODE** switchen. Zet de jacuzzi in de **CONFIG mode** >> Op het scherm verschijnt dan: " - - - -"

1 Use of the jacuzzi by the tenants.


- ✓ The tenants use the jacuzzi **ONLY in USER “WELCOM” mode !!**
- ✓ The jacuzzi is **ALWAYS** in **CONFIG “- - - -” mode when NO USE**


1.1 BEFORE using the Jacuzzi

If you are going to use the jacuzzi, first put the jacuzzi in the USERS “WELCOM” mode !!

- This will leave the clock and automatic configuration for daily heating and filtering unchanged. If the tenant uses the jacuzzi in the **CONFIG “- - - -” mode**, there is a chance that you accidentally change the configuration.
- **NEVER use the jacuzzi and the buttons as a tenant in the CONFIG mode “- - - -”.**

Before using the jacuzzi, **put it in USER mode FIRST:**

1. Unlock the Jacuzzi by pressing the “UNLOCK”  button.
2. Check which mode the jacuzzi is in.
 - I. User mode >> on the screen you will see: “WELCOM”
 - II. CONFIG mode >> on the screen you will see: “- - - -”



3. With the red button “OFF”  you can switch the jacuzzi from **STATUS IN MODE**. Put the jacuzzi in USER mode >> The screen will then show: “WELCOM”

1.2 AFTER using the jacuzzi

Do you go out of the jacuzzi and close the jacuzzi. Then make sure you **ALWAYS** put the jacuzzi back in the **CONFIG “- - - -” mode**.

- This ensures that the daily automatic heating and filtering process can do its job, so that you also have a heated and clean jacuzzi the next day.
- **NEVER leave** the jacuzzi in the **USER mode “WELCOM”** after use as a tenant.

put the jacuzzi **BACK in CONFIG mode AFTER use:**

1. Unlock the Jacuzzi by pressing the “UNLOCK”  button.
2. Check which mode the jacuzzi is in.
3. With the red button “OFF”  you can switch the jacuzzi from **STATUS IN MODE**. Put the jacuzzi in **CONFIG mode** >> The screen will then show: “- - - -”