


## 1 De jacuzzi sproeiers


De vraag aan elke huurder om voorzichtig de afsluitdeksel van de Jacuzzi te halen bij gebruik !!

De 2 sproeiers van de jacuzzi moeten altijd in de “**GESLOTEN STAND**” staan, als de afsluitdeksel er weer op gaat. De sproeiers kunnen open gaan als de verwarming aan gaat, wanneer deze handmatig niet in de juiste stand dicht staan. Als de volgende keer de deksel er af gehaald wordt en de sproeiers blijven hangen achter de deksel, is de kans aanwezig dat de sproeiers beschadigen.

- **WEES VOORZICHTIG** met openen van de deksel !! De sproeiers kunnen open staan aan de voor en achterkant (2 stuks).
- **Attentie:** Zorg daarom altijd dat de sproeiers **met de zwarte draaiknop** op de rand **NA GEBRUIK** echt afgesloten zijn, voordat je de jacuzzi weer gaat afsluiten.. (Zie foto)
- **MET DE KLOK MEE**, dan zet je de sproeiers in de “**GESLOTEN STAND**”.



### 1.1.1.1 Controleer of sproeiers DICHT STAAN

1. Wil je controleren of de sproeiers echt dicht staan, dan moet je dit doen wanneer de verwarming aan staat. De verwarming is de trigger om de sproeiers te activeren, mits ze in de open stand staan. Het beste is dus om ze dicht te draaien wanneer de verwarming aan staat. Dan weet je het zeker.
- 2.
3. Controle of de sproeiers echt dicht staan, kan alleen als de verwarming ook aan staat. De verwarming kan je aanzetten **tussen 13:00 en 23:00**.
4. Eerst de bediening ontgrendelen door op de knop “**UNLOCK**”  te drukken.
5. Check in welke mode de jacuzzi staat. Gebruikers mode “**WELCOM**” of auto mode “- - - -”.
6. Met de rode uitknop “**UIT**”  kan je de jacuzzi mode switchen. Zet de jacuzzi in de gebruikers mode “**WELCOM**”
7. Zet de heater aan met “**PREHEAT**”  en check of de sproeiers open gaan.
8. Staan ze open, dan draai je deze met de knop op de rand van de jacuzzi dicht (zie filmpje). Met de klok mee draai je de sproeiers in de “**GESLOTEN STAND**”.
9. Zet de jacuzzi na de controle terug in de auto mode “- - - -” met de rode knop “**UIT**” , zodat de jacuzzi dagelijks automatisch filtert en verwarmd tot de ingestelde temperatuur.

Waar nodig is de eigenaar of de poolbeheerder ook bereikbaar.


# 1 The jacuzzi sprinklers

The question to every tenant to carefully remove the lid from the Jacuzzi when using it !!

The 2 jets of the jacuzzi must always be in the “CLOSED POSITION” when the cover is put back on.

The sprinklers can open when the heater is switched on, if the sprinklers are not set manually in the “closed” position. If the lid is removed the next time and the nozzles get stuck behind the lid, there is a chance that the nozzles will be damaged.






- **BE CAREFUL** when opening the lid !! The nozzles can be open upwards at the front and rear (2 pieces).
- **Attention:** Always make sure that the nozzles **with the black knob** on the edge are really closed **AFTER USE**, before you close the jacuzzi again. (See photo).
- **CLOCKWISE**, then put the sprinklers in the “CLOSED POSITION”.



## 1.1.1 Check, if the sprinklers are CLOSED

If you want to check whether the sprinklers are really closed, you must do this when the heater is on. The heater is the trigger to activate the sprinklers, provided the sprinklers are manually still in the “open” position. It is therefore best to close them when the heater is on. Then you know for sure.

You can only check whether the sprinklers are really closed, if the heater is also on. You can use and switch on the heater **between 13:00 and 23:00**.

1. First unlock the controls by pressing the “UNLOCK”  button.
2. Check which mode the jacuzzi is in. User mode “WELCOM” or auto mode “- - - -”.
3. With the red off button “OFF”  you can switch between the jacuzzi modes. Put the jacuzzi in user mode “WELCOM” .
4. Switch on the heater with “PREHEAT”  and check whether the nozzles open.
5. If they are open, close them with the button on the edge of the jacuzzi. (see video) Turn the sprinklers clockwise to the “CLOSED POSITION”.
6. After the check, put the jacuzzi back in auto mode “- - - -” using the red button “OFF” , so that the jacuzzi automatically filters and heats to the set temperature every day.

Where necessary, the owner or the pool manager can also be reached.